



GAMESPACE/ TRUESPACE  
TORQUE DTS EXPORTER DOCUMENTATION

---



# TABLE OF CONTENTS



- Setting Up Your Object For Export** . . . . . 3
  - Object Orientation . . . . . 3
  - Working With Layers . . . . . 3
- Configuring Torque Material Properties** . . . . . 4
  - Torque Material Property Settings . . . . . 4
- Using The Features Of The DTS Format.** . . . . . 5
  - The Bounds Object . . . . . 5
  - Ground Transform . . . . . 5
  - Mipmap Control . . . . . 5
  - Level Of Detail . . . . . 6
  - Auto Level Of Detail. . . . . 6
  - Collision Objects . . . . . 7
  - Line Of Sight Collision Objects . . . . . 8
  - Named Nodes . . . . . 9
  - Bilboards . . . . . 11
  - Bilboard Details . . . . . 11
  - Miscellaneous Layer Flags . . . . . 11
- Animation** . . . . . 12
  - Supported Animation Types. . . . . 12
  - Future Animation Support . . . . . 12
  - Using Clips For Animation Export . . . . . 12
  - Clip Properties. . . . . 12
  - Clip Flags . . . . . 12
  - Exporting Animation . . . . . 13
  - DSQ Export . . . . . 13
- Configuration Data** . . . . . 13
- Triggers** . . . . . 13

Much of the basic DTS feature documentation in this file was assembled in part from other tutorials and docs created by various members of the Garage Games Community, most notably Logan Foster & Joe Maruschak and thanks to Tim Gift and Clark Fagot for their help along the way. Also, special thanks to Stan Melax and the beta testers who weren't afraid our software would erase their hard drives.

# SETTING UP YOUR OBJECT FOR EXPORT



## Object Orientation

Proper object orientation of your DTS object is created by using the default view positions of GameSpace. Positive Y is forward, and Z is up.

## Working With Layers


This exporter is heavily reliant on the use of layers to configure the various settings and options you can employ to create your DTS object.

The layers tool bar is located on the top left hand side of the GameSpace screen. You can add new layers to your scene by clicking the “add layer” button at the bottom of the layers tool bar. You can also Show, Lock and Hide all of the objects on any given layer by holding down the left mouse button over one of the layer icons and selecting the desired option from the flyout menu.

Right clicking on the “add layer” button will open the layer information dialog box. From here you can select any layer in your scene and rename it to activate several features of this DTS exporter.

Right clicking on the object tool will open the Object Inspector. From here you can also rename layers and move the objects in your scene from layer to layer.

Each layer in your scene represents a detail level of your exported DTS object.




Add Layer

### Layer Information



### Object Inspector



Object Tool



## Material Shader Setup

load a texture shader.

load plain transparency and set the trans value to 1

load a environment map shader.

load your texture into the texture map shader.

In your environment map shader use these settings

1. Set luminance to 0
2. Set diffusion to max
3. Set shininess to 0
4. Set specular to 0

This will create a neutral texture only setup for the DTS export. Leaving the color shader as a solid color will create a DTS without materials.



**Note:** This exporter supports the use multiple textures on your DTS object. Per face or per distinct object. In game performance issues can arise depending on the size and number of textures on your object.

## DTS Material Properties

### Self Illumination

Set Luminance to anything  $> 0$  ;

Self Illuminate is turned on

### Material Transparency

Set Transparency  $< 1$  ; Transparency is turned on

Transparency is based off of the texture map alpha channel (must use png)

### Subtractive Transparency

Turn on transparency

Set specular  $> 0$  but  $< 1$  ; Then Subtractive is on

Transparency is based off of the texture map alpha channel (must use png)

### Additive Transparency

Turn on transparency

Set specular = 1(max) Then Additive is turned on

Transparency is based off of the texture map alpha channel (must use png)

### Environment Mapping

Set reflection  $> 0$  ; Then Reflection is turned on

Reflectivity is based off of the alpha channel of texture loaded into the environment map shader (must use png)



Transparency

Environment Map





## Using Layers

Layers are used to control how geometry is exported to your DTS file. Any object that is not placed on a layer is ignored by the exporter.


Layer should be renamed from their default number to a more descriptive name.

### Examples: “Mesh Layer” or “Vehicle Body”

A colon should follow the name of a layer, followed by comma separated flag names as required:

Layer naming convention:

**“Layer name: flag, flag, etc...”**



## The Bounds Object

The DTS format requires a bounds object that surrounds your DTS object. You can optionally add a custom box this layer to be used as the bounds object. The size of the bounds object is calculated automatically if no object is found on the bounds layer.

The orientation of the bounding box defines the orientation of the object. When you create the bounds, you are creating a mini world that defines how the object will orient itself in the Torque Engine

**Usage: add a layer named “bounds:”**

## Mipmap Control Flags:

By default, textures are mipmapped but you can add flags to the bounds layer to change how or if mipmaps are generated.

### **no\_mipmap**

do not generate mipmaps for any textures

### **no\_mipmap\_trans**

If you want most textures to mipmap, but not translucent textures

### **no\_black\_border**

Translucent textures that do not tile are considered "zeroborder" textures -- that is, we assume that there is a blackborder around the texture and we enforce this in the mipmap. This is normally what one wants, because otherwise streaks occur when off-tile parts of the face are drawn. If you don't want to do this to your non-tiling translucent textures, then you can turn it off using this flag.

## Ground Transform (not exported yet)

Animation sequences that move the character must have ground transform. The engine knows that the character has a specific velocity in all directions (this is set in script).

Ground transform is based on the animation of the bounding box. If you want to export a running person, you would place the bounding box around the person at time 0, with the origin of the box at the persons feet. As the person runs, you would animate the bounding box to keep pace with the person.

If you have no ground transform, the animation will not play when the character moves.

## Level Of Detail

Level of Detail Layers are used to store high and low polygon versions of your DTS object. The size value tells the Torque engine when to switch from one detail level to another. This is used to reduce the amount of geometry on screen as objects move further away from the camera.

You can manually create detail levels by creating a new layer and adding size flag to its name. On this layer you can place a mesh with less detail than your primary mesh.

### **size=xxx**

Where xxx = detail level size.

This is used for detail level layers.

**Example Use: "Detail Level 1: size=20"**

## Auto Level Of Detail

Using the autoLOD flag in combination with the size flag will allow the exporter to automatically generate detail level meshes for your model.

### **autoLOD=xxx**

Where xxx = polygon reduction.

This is used for automated detail level layers.

**Example Use: "Detail1: size=80, autoLOD=80"**

The number is based of 100% so in this example 80 = 20% polygon reduction.

When using LOD your highest detail level ( Your primary object mesh ) must also have a size flag.



2200 Triangles

### AutoLOD Example Usage

Layer Name:  
Mesh Layer: size=145

Original Mesh Layer  
no autoLOD flag



1100 Triangles

Layer Name:  
Detail1: size=80, autoLOD=50

Auto Generated Mesh  
50% Triangle Reduction



770 Triangles

Layer Name:  
Detail2: size=20, autoLOD=35

Auto Generate Mesh  
65% Triangle Reduction

## Collision Objects

Collision meshes are used to perform collision tests within the Torque Game Engine. Collision objects should be very simple shapes and can not be concave (They can not indent or push into them at any location)

This exporter supports box, cylinder collision or 1 to 9 custom collision meshes. If your object does not require collision do not add collision layers to your scene.

### Box Collision:

Add a layer named “**collision: box**”  
Objects on this layer are ignored by the exporter

### Cylinder Collision:

Add a layer named “**collision: cylinder**”  
Objects on this layer are ignored by the exporter


### Custom Collision Meshes:

To add a custom collision mesh add 1-8 layers named collision1, collision2, etc...


On each layer you can have a custom collision mesh. Vehicles are limited to ONE collision mesh for the collision shape.

Complex collisions can be created using multiple simple collision shapes

**Collision meshes can not be concave.**



Bad collision (concave)



Good collision. Two separate collision objects

## Line Of Sight Collision Objects

Line of sight collision objects are used to test projectile collision on a DTS object. Things like bullets or lasers striking a DTS object. Creation is similar to that of normal collision objects

This exporter supports box, cylinder collision or 1 to 9 custom LOS collision meshes. If your object does not require LOS collision do not add LOS collision layers to your scene.

### Box LOS Collision:

Add a layer named "loscollision: box"  
Objects on this layer are ignored by the exporter

### Cylinder LOS Collision:

Add a layer named "loscollision: cylinder"  
Objects on this layer are ignored by the exporter


### Custom LOS Collision Meshes:

To add a custom LOS collision mesh add 1-8 layers named: loscollision1, loscollision2, etc...


On each layer you can have a custom LOS collision mesh. Keep the detail meshes as low in polygon count as possible as this is processor intensive. (Vehicles should only have one)

LOS Collisions can be created using multiple simple LOS collision shapes

**Collision meshes can not be concave.**



Bad loscollision (concave)



Good loscollision. Two separate loscollision objects



## Named Nodes

Named nodes are used to support special features of the Torque Engine. In order for Players, weapons and vehicles to function properly certain nodes must exist on a layer named "Nodes".

Left clicking on the DTS exporter icon will open the exporter dialog box. From here either type a node name into the or choose one from the drop down list and click "Add Node". If the node layer does not exist the exporter will add the layer for you.

Nodes are created with 0,0,0 rotation and are oriented in the default view. It is sometimes helpful to view scene through a node to make sure the node is oriented properly. You can resize nodes as you wish only placement and orientation are important.

The colored face of the node indicates the direction the node is currently facing.

## Character & Static Object Nodes

**Cam:** Required only for playable characters. The "cam" node is used to tell the engine where to view the model from if the camera perspective is placed into 3rd person mode. Without this node you will view from the transform coordinates of the "bounds" shape.

**Eye:** Required only for playable characters, this node is essentially just a set of transform coordinates that tells the engine where to place the camera for viewing from 1st person perspective.

**Light#:** Light Emitter node

**Mount#:** Mount nodes are used to tell the engine that something can be attached to your model at this position. For example you would use a mount node to tell the engine where to place a weapon on your player model.

**Ski#:** Ski Marker node





## Weapon Nodes

**Ejectpoint:** This node tells the engine where to emit the shell casing DTS file from when the weapon is fired.

**Mountpoint:** This node tells the engine where to attach the weapon to the player model. The weapon is attached specifically at the location of the "mountpoint" to the corresponding "mount" node on the player character.

If there is no mountpoint in the DTS file or if the node is not exported, the engine will default to the origin (0,0,0) of the DTS file when mounting.

**Muzzlepoint:** Weapon Muzzle Flash node. The "muzzlepoint" node tells the engine where to show the 'flash' or 'bang' DTS file when the weapon is fired.

## Vehicle Nodes

**Cam:** Required only for playable characters. The "cam" node is used to tell the engine where to view the model from if the camera perspective is placed into 3rd person mode. Without this node you will view from the transform coordinates of the "bounds" shape.

**Contrail#:** This emitter creates contrails, which are those little wisps that you see that emit from the tips of wings on airplanes.

**Eye:** Required only for playable characters, this node is essentially just a set of transform coordinates that tells the engine where to place the camera for viewing from 1st person perspective.

**Hub#:** For Wheeled Vehicles. Hub nodes are used to define where a wheel DTS shape will attach to the mesh when it is in the engine. Example Usage: hub0, hub1, hub2, hub3

**JetNozzle#:** This node tells the engine where to emit a jet engine exhaust from.

**Light#:** Light Emitter node

**Mount#:** Mount nodes are used for two things with vehicles in TGE, either as a player attachment point or as a weapon location. Typically mount nodes will be used or assigned to the following functions:

- Mount0 pilot of vehicle
- mount1 navigator/gunner
- mount2 passenger
- mount3 passenger
- mount4 passenger
- mount5 passenger
- mount6 passenger
- mount7 passenger
- mount8 passenger
- mount9 Weapon (bomb bay)
- mount10 Weapon (gun)

**Smoke\_node#:** These nodes denote the location of a particle system to the engine. This particular particle system emits particles based on the amount of damage that your vehicle has taken. To place this node on your vehicle, create a dummy helper object and link it to the location on your mesh where you would like the damage smoke to emit from in the game.



## Billboards

Billboard are objects (usually 2d) that always face the player. For example, you could have an explosion in which shrapnel flies out from the center and also have little explosion balls fly out that are just flat polygons that always face you.

Adding the billboard or billboardz flag to a layer name will cause the exported object(s) on that layer to always face the player.

### **billboard**

Tells the exporter that the object(s) on this layer always face the player

**Example Use: "Mesh Layer: billboard"**

### **billboardz**

Tells the exporter that objects on this layer always face the player on their Z axes

**Example Use: "Mesh Layer2: billboardz"**

## Billboard Detail Levels

The billboard layer flag and the size flag can be used in combination to create billboard detail levels.

This will create a detail level composed of two or more triangles that will always face the camera.

**Example Use: "Detail6: size=12, billboard"**

## Miscellaneous Layer Flags

Named nodes are used to support special features of the Torque Engine. In order for Players, weapons and vehicles to function properly certain nodes must exist on a layer named "Nodes".

### **Sort**

Tells the exporter to sort the mesh on this layer for proper display of objects with transparency.

**Example Use: "Mesh Layer: sort"**

### **no\_strip**

Tells the exporter not to use tri-stripping for the objects on this layer.

**Example Use: "Mesh Layer: no\_strip"**

### **enormals**

Encode normals

**Example Use: "Mesh Layer: enormals"**



## Supported Animation Types

**Transform Animation:** Often referred to as skeletal animation or node animation, this type of animation is created by building a skeleton for your model and animating it using key frames stored clips.

## Future Animation Support

**Texture animation:** Enables animation of Texture Coordinates. This is useful for things where the texture itself must animate. Scrolling computer monitors, waterfalls, and tank treads are just a few of the applications for animated texture coordinates.

**IFL animation:** Allows you to export Image File Lists. These are a sequence of image files, and are useful for things like explosions

**Visibility Animation:** Use of animated object transparency.

## Using Clips For Animation Export

Sequences are created using by using animation clips in GameSpace and TrueSpace 6.5+

## Clip Properties:

**Loop:** If checked, the sequence will be set to cyclic, if unchecked, the sequence will play once and then stop.

**Complete cycle:** Set by turning on "Toggle" for a clip, the exporter will add a reverse copy of the clip frames so the sequence will cycle back to its start.


## Clip Flags

**fps=xxx:** All clips use the frame rate supplied in the frame rate box under animation options. If set, export xxx frames where xxx is the number supplied in the flag.

**priority=xxx:** controls what sequence controls a node when two sequences (running on different threads) want to control the same node.

**blend:** This will allow additive animation. These will not conflict with other threads, and can be played on top of the node animation threads.

**Example use: "Jump: fps=20, priority=02"**



## Exporting Animation

To export animation for your DTS object, left click the exporter icon to open the exporter dialog box. Then click the "export animation" check box and choose between the named animation clips in your scene in the DTS shape or as separate DSQ files. Then click the export button to export your DTS and animation

## DSQ Export

Exporting DSQ files exports the animation separately from the DTS file. Each named animation clip in your scene is exported as a separate DSQ file using the clip name as the file name.

## Configuration Data (not supported yet)

There are a number of parameters used by the exporter that are read from the object notes.

By default, all transform animation in a shape during a sequence is exported. If a node differs from the default position in a sequence then the transform on that node is considered animated even if it is unchanging throughout the sequence.

The default position for all nodes is determined by the node position at frame 0 in your scene. Commands are used to determine which nodes are being exported to a particular thread, force export needed nodes, manually cull out useless nodes (or ones with potential conflicts) and otherwise take steps to ensure that threads do not fight for control of the same nodes.

DTS Exporter Dialog Box



## Triggers (not supported yet)

You can have up to 32 triggers (1-32) which are turned on using the configuration data stored in the object notes of your scene.

As an example, the easiest way to deal with footsteps is to have one trigger for each foot (1=left, 2=right, say). You may have an application where you want to know when the foot is supposed to be on the ground. In that case you would turn on the "foot on ground" state when it first contacts the ground and turn it off when the foot leaves. Thus each foot would have 2 trigger keys: a + one when the foot hits the ground and a - one when it leaves.

If you want your character to leave footprints, all you have to do is go to the trigger track of the appropriate sequence and add a trigger key and a value. In the default Torque engine, 1 = left foot, 2 = right foot.